

# Tastenbelegung Typ Compact rechts ohne Zahlenfeld

Gorlo&Todt

Stand: 4/2014

Prog <sup>o</sup>	F1	F2	F3	F4	F5	F6	F7	F8	F9	F10 Rol	F11 <sup>o</sup> Caps	F12 <sup>o</sup> Pau	Esc <sup>o</sup>	Pos1	Ende
^ <sup>o</sup>	1	2	3	4	5	6	7	8	9	0	ß	Tab	←	Einf	B↑
;	Q	W	E	R	T	Z	U	I	O	P	Ü	+	↵	Entf	B↓
<>	A	S	D	F	G	H	J	K	L	Ö	Ä	#		↑	
Shf <sup>o</sup> Li <sup>o</sup>	Y	X	C	V	B	N	M	,;	.:	-_	Shf re <sup>o</sup>		←	→	
Stgl <sup>o</sup> Mak <sup>o</sup>	Dru	€	Space		Space		@	App	Win <sup>o</sup>	Alt <sup>o</sup>	Ägr <sup>o</sup>	Stgr <sup>o</sup>	↓		