

Gorlo&Todt Belegungsplan
externes Zahlenfeld
Typ Zeusnum

←	Num	÷	×
7	8	9	-
4	5	6	+
1	2	3	Enter
0	.	,	